



N° Réf.	N° Pièce	Désignation
1	11111-10300	Cylinder Head
2	11141-10300	Gasket
3	11152-45000	Rubber Pad
4	11251-29300	Rubber Pad
5	08316-16088	Nut
6	09482-00091	Spark Plug (ngk, B8es)
6	09482-00196	Spark Plug (nd, W24es-u)
7	11210-10301	Cylinder
8	09206-13001	Pin
9	09108-08056	Stud Bolt (18*120)
10	09108-08057	Stud Bolt (18*130)
11	11241-10200	Gasket, Cylinder
12	11251-10200	Rubber Pad, Side
13	11251-10300	Rubber Pad, Front
14	09343-05129	Hose, Breather (l:240@r200)


GT200E1



N° Réf.	N° Pièce	Désignation
1	11300-10830	Crankcase Set
2	09206-13001	. Pin
3	01517-08858	. Bolt (8*85)
4	01517-08758	. Bolt (8*75)
5	01517-08658	. Bolt (8*65)
6	01517-08558	. Bolt (8*55)
7	01517-08358	. Bolt (8*35)
8	01517-06908	. Bolt (6*90)
9	01517-06808	. Bolt (6*80)
10	01517-06658	. Bolt (6*65)
11	01517-06608	. Bolt (6*60)
12	01517-06508	. Bolt (6*50)
13	01517-06308	. Bolt (6*30)
14	09247-14007	Plug, Drain
15	09168-14004	Gasket
16	09100-10040	Bolt, Mounting (10*145)
17	09100-10051	Bolt, Mounting (10*125)
18	01107-08758	Bolt, Mounting (8*75)
19	08321-31088	Lock
20	08322-11088	Washer
21	08322-11108	Washer
22	08319-31108	Nut




GT200EX



N° Réf.	N° Pièce	Désignation
1	11341-10301	Cover, Clutch
2	11482-10200	Gasket
3	09206-13001	Pin
4	02112-06508	Screw (6*50)
5	02112-06358	Screw (6*35)
6	68233-36200	Emblem
7	09259-19001	Plug, Oil Filler
8	09128-06004	Plug, Oil Level
9	09168-06001	Gasket
10	11351-10300	Cover, Magneto
11	11483-10200	Gasket
12	09206-13001	Pin
13	02112-06508	Screw (6*50)
14	02112-06358	Screw (6*35)
15	68233-36200	Emblem
16	11361-10300	Cover, Engine Sprocket
17	02112-06458	Screw (6*45)
18	02112-06557	Screw (6*55)
19	11387-10300	Cap, Release Adjust
20	02112-05088	Screw
21	11382-10200	Cover, Starter Motor
22	11493-10200	Gasket
23	01107-06208	Bolt
24	09100-06011	Bolt


GT200EX




N° Réf.	N° Pièce	Désignation
1	12110-10203	Piston (std)
1	12110-10203-050	Piston (os:0.5)
1	12110-10203-100	Piston (os:1.0)
2	12140-28630	Ring Set, Piston (std)
2	12140-28630-050	Ring Set, Piston (os:0.5)
2	12140-26530	Ring Set, Piston (os:1.0)
3	12151-07000	Pin, Piston
4	09381-14001	Circlip
5	09263-14006	Bearing
6	12200-10300	Crankshaft Assy
7	12161-12002	. Rod, Connecting
8	12211-10302	. Pin, Crank
9	09160-19001	. Thrust Washer (19*32*1)
10	09263-19009	. Bearing
11	12221-10300	. Crankshaft, Rh
12	12231-10300	. Web, Crank
13	12241-10300	. Crankshaft, Middle
14	12261-10301	. Crankshaft, Lh
15	09262-25036	. Bearing, Rh (25*62*17)
16	08211-25343	. Thrust Washer
17	09262-25034	. Bearing, Lh & Middle
18	09289-30007	. Oil Seal, Middle
19	09390-62009	C Ring, Rh
20	09160-20025	Washer (20*48*1)
21	21111-10200	Gear, Primary Drive
22	26421-10300	Gear, Tachometer Drive No.1
23	09164-16002	Washer
24	09140-16002	Nut
25	08341-31059	Key


N° Réf.	N° Pièce	Désignation
---------	----------	-------------

1	12611-10201	Gear, Starter Idle
2	09206-13003	Pin
3	08211-14201	Washer
4	12600-10830	Starter Clutch Set
5	09261-15001	. Roller
6	09440-04015	. Spring
7	12633-31000	. Piece, Push
8	09106-08006	Bolt
9	09263-25020	Bearing
10	08211-25381	Washer
11	12649-45000	Shim, Starter Clutch






N° Réf.	N° Pièce	Désignation
11	13201-10301	Carburetor Assy, Rh
11	13202-10301	Carburetor Assy, Lh
1	13251-36210	. Gasket
2	13254-01010	. Pin, Float
3	13370-46710	. Valve Assy, Needle
4	02112-03088	. Screw
5	13373-46710	. Plate, Needle Valve
6	13247-05010	. Plug, Drain
7	13249-05010	. Gasket
8	09492-20002	. Jet, Pilot (20)
9	13267-36500	. Screw, Stop
10	13268-35010	. Spring
11	13295-33010	. O Ring
12	13252-36110	. Float
13	13382-03110	. Washer
14	09491-82002	. Jet, Main (82.5)
15	13383-10301	. Needle, Jet (4cg1-3)
16	09494-00255	. Jet, Needle (o-8)
17	13394-10010	. E Ring
18	13581-10300	. Plate, Spring
19	02112-04168	. Screw
20	08321-21048	. Lock Washer
21	13684-30650	. Hose, Over Flow (l:140)
22	13551-10300	. Valve, Throttle Rh
23	13561-10300	. Valve, Throttle Lh
24	13661-16600	. Nut
25	13577-48110	. Adjuster, Cable
26	1361-33010	. Boot
27	13573-08210	. Spring
28	13683-39110	. Hose, Breather (l:200)
29	13269-15010	. Screw, Air
30	13295-33010	. O Ring
31	13268-35010	. Spring
32	02112-05068	. Screw
33	13523-46110	. Gasket
34	13803-10200	. Hose, Starter (l:40)
35	13683-10200	. Hose, Fuel (l:27)
36	13617-11300	. Clip




N° Réf.	N° Pièce	Désignation
1	13700-10210	Cleaner Assy, Air
2	13780-10200	. . Filter Assy
3	13781-10200	.. . Filter
4	08310-11058	. . Nut
5	08322-21058	. . Washer
6	13740-10210	. . Cap
7	02112-05168	. . Screw
8	08321-21058	. . Lock Washer
9	08322-21058	. . Washer
10	02112-06168	Screw
11	08321-21068	Lock Washer
12	08322-21068	Washer
13	09402-42306	Clamp, Air Inlet Hose
14	13110-10300	Pipe, Intake
15	13121-10200	Gasket
16	02112-06208	Screw
17	09402-38303	Clamp

GT200EX




N° Réf.	N° Pièce	Désignation
1	14181-11010	Gasket, Exhaust Pipe
2	01107-08208	Bolt
3	08321-21088	Lock Washer
4	14150-10300	Pipe, Exhaust Rh
5	14160-10300	Pipe, Exhaust Lh
6	14771-10300	Connector
7	14780-10300	Cover, Rh
8	14790-10300	Cover, Lh
9	02112-05068	Screw
10	02112-05168	Screw
11	14301-10310	Muffler Assy, Rh
12	14302-10310	Muffler Assy, Lh
13	14510-39002	• . Pipe, Baffle
14	09128-05004	• . Screw
15	08321-21058	• . Lock Washer
16	01107-06208	Bolt
17	08322-11088	Washer
18	08321-21088	Lock Washer






N° Réf.	N° Pièce	Désignation
1	16100-10210	Pump Assy, Oil
2	16731-03101	Gasket
3	02112-05168	Screw
4	02112-05308	Screw
5	08321-21058	Lock Washer
6	16391-05031	Piece
7	16292-03111	Terminal, Cable
8	09119-08014	Bolt
9	08310-12088	Nut
10	16810-10200	Hose, Oil Inlet
11	09360-06003	Union Bolt
12	09168-06004	Gasket
13	09401-08401	Clamp
14	16821-29300	Hose, Oil Outlet
15	09401-04401	Clip
16	16831-10200	Grommet
17	11385-10200	Cap, Inspection
18	02112-06088	Screw

GT200EX




N° Réf.	N° Pièce	Désignation
1	21200-10200	Gear Assy, Primary Driven
2	09180-20068	Spacer
3	21410-28700	Hub, Sleeve
4	09167-17002	Washer
5	09140-16001	Nut
6	08211-17282	Thrust Washer
7	21441-28300	Plate, Drive
8	21451-28000	Plate, Driven
9	21460-28000	Disk, Pressure
10	09443-12010	Spring
11	09261-02001	Pin
12	23111-10000	Rod, Push (l:123)
13	23111-10200	Rod, Push (l:112)
14	09285-06009	Oil Seal
15	23121-39100	Piece, Push
16	09263-10002	Thrust Bearing
17	23211-36200	Screw, Clutch Release
18	23212-07202	Arm, Clutch Release
19	09134-06001	Screw
20	09160-06020	Washer
21	08310-22068	Nut
22	23241-36200	Cover
23	23245-36200	Holder, Dust Seal
24	09281-05001	Dust Seal
25	03111-05128	Screw
26	08322-21058	Washer
27	23222-07000	Piece, Arm End
28	09440-08001	Spring

GT200EX




N° Réf.	N° Pièce	Désignation
1	24120-10300	Countershaft Assy
2	24121-10200	. . Shaft, Counter (nt:12)
3	24221-10300	. . Gear, 2nd Drive (nt:16)
4	24231-10300	. . Gear, 3rd Drive (nt:20)
5	24241-10301	. . Gear, 4th Drive (nt:23)
6	24251-10300	. . Gear, 5th Drive (nt:24)
7	09380-20003	. . Circlip
8	08160-63040	Bearing, Rh
9	09263-15011	Bearing, Lh
10	09390-52002	Ring, Rh
11	09399-30003	Ring, Rh
12	24131-10201	Shaft, Drive
13	24310-10200	Gear, 1st Driven (nt:33)
14	24320-10300	Gear, 2nd Driven (nt:28)
15	24331-10300	Gear, 3rd Driven (nt:25)
16	24341-10301	Gear, 4th Driven (nt:23)
17	24351-10300	Gear, 5th Driven (nt:21)
18	08211-15262	Washer
19	09167-20007	Washer
20	09380-20003	Circlip
21	09300-15007	Bushing, Rh
22	09262-20047	Bearing, Lh
23	09283-26014	Oil Seal, Lh
24	09390-47002	C Ring, Lh
25	24741-10201	Retainer
26	02122-06128	Screw
27	27511-29001	Sprocket, Engine (nt:12)
28	09280-20001	O Ring (1*19.5)
29	09180-20069	Spacer (20*26*17)
30	09167-20006	Washer
31	09140-20001	Nut
32	27600-10210	Chain Assy, Drive (520*98l)
33	27620-36110	. . Joint




N° Réf.	N° Pièce	Désignation
1	25211-10200	Fork, No.1
2	25221-10200	Fork, No.2
3	25411-48000	Shaft, Fork
4	02142-06108	Stopper, Fork Shaft No.1
5	25451-10200	Stopper, Fork Shaft No.2
6	25311-10300	Cam
7	09209-04013	Pin
8	09261-04002	Pin
9	25322-10300	Retainer, Drive Pin
10	02122-06168	Screw
11	25341-03000	Guide, Cam
12	01107-06128	Bolt
13	25350-10200	Stopper, Cam No.1
14	09443-08005	Spring
15	09111-06003	Bolt
16	25351-18000	Stopper, Cam No.2
17	09440-05018	Spring
18	09168-14004	Gasket
19	25352-11000	Housing, Cam Stopper
20	25510-10201	Shaft, Gear Shifting
21	09180-12083	Spacer
22	09443-08017	Spring
23	09444-26012	Spring
24	25671-01000	Stopper, Arm
25	09285-12002	Oil Seal
26	25600-10300	Lever Assy, Gear Shifting
27	25652-16500	• Rubber
28	09100-06091	Bolt
29	37720-10200	Body, Gear Shifting Switch
30	37712-10200	Gasket
31	02112-05128	Screw
32	09209-05011	Contact
33	09440-04010	Spring


GT200EX




N° Réf.	N° Pièce	Désignation
1	26211-10200	Shaft, Kick Starter
2	26231-34000	Starter, Kick
3	09440-32002	Spring
4	08212-22342	Plate
5	09380-22006	Circlip
6	26221-10200	Guide, Spring
7	09448-45009	Spring
8	09285-16002	Oil Seal
9	26232-36001	Guide, Kick Starter
10	02122-06168	Screw
11	26241-10300	Gear, Drive (nt:35)
12	09301-20003	Bushing
13	09300-17002	Bushing
14	04221-07129	Pin
15	26300-39100	Lever Assy, Kick Starter
16	26352-01000	• Rubber
17	01107-08258	Bolt

N° Réf.	N° Pièce	Désignation
1	26421-46100	Gear, Tachometer Drive No.2
2	26422-22701	Shaft
3	08211-10201	Thrust Washer
4	08331-31109	Circlip
5	26423-46100	Gear, Tachometer Drive No.3
6	26424-46100	Retainer
7	26431-10300	Gear, Tachometer Driven
8	26441-48000	Sleeve
9	09160-08003	Thrust Washer
10	08280-10001	O Ring
11	08135-06002	Bolt






N° Réf.	N° Pièce	Désignation
1	31100-10200	Motor Assy, Starting
2	31311-10200	. . Armature
3	31151-10200	. . Housing, Drive
4	31153-45010	.. . Oil Seal
5	31361-10200	. . Shim
6	31170-10200	. . Housing, Commutator End
7	31135-65010	.. . Spring, Brush
8	31131-10200	.. . Brush (-)
9	31130-10200	. . Brush (+)
10	31281-10200	. . Screw
11	08310-32068	. . Nut
12	08321-21068	. . Lock Washer
13	01107-06128	Bolt
14	09280-24001	O Ring




N° Réf.	N° Pièce	Désignation
1	32100-10200	Magneto Assy
2	32101-10200	• . Stator Assy
3	32131-10200	•• .. Coil, Lighting A
4	32132-10200	•• .. Coil, Lighting B
5	32351-10200	•• .. Screw
6	32140-10200	•• .. Coil, Primary
7	32351-10210	•• .. Screw
8	32151-10200	•• .. Coil, Pulser
9	02112-04208	•• .. Screw
10	08321-21048	•• .. Lock Washer
11	32102-10200	• . Rotor
12	02112-06168	Screw
13	08341-31039	Key
14	08322-11128	Washer
15	08321-21128	Lock Washer
16	08310-12128	Nut
17	32371-10200	Clamp
18	32900-10200	C.d.i. Unit Assy
19	02112-06128	Screw
20	33410-10200	Coil Assy, Ignition
21	02112-06208	Screw
25	33510-39110	Cap, Spark Plug
26	33542-98000	Seal, High Tension Cord

GT200X X






N° Réf.	N° Pièce	Désignation
1	33610-10310	Battery (12v,8ah)
2	33820-44000	Lead Wire, (+)
3	33850-10200	Lead Wire, (-)
4	33624-45000	Cap, Terminal (+)
5	33652-32200	Cushion
6	33680-36200	Hose, Exhaust
7	41540-10200	Holder, Battery
8	02112-06128	Screw
9	08322-21068	Washer
10	08321-21068	Lock Washer
11	09462-00008	Banc




GT200E X

N° Réf.	N° Pièce	Désignation
1	34110-11332	Speedometer Assy
2	34210-11301	Tachometer Assy
3	34173-11300	Socket
4	09471-12001	Bulb (12v, 3.4w)
5	34951-11300	Bracket
6	34961-36322	Under Plate, Speedometer
7	34962-36322	Under Plate, Tachometer
8	34955-44020	Cushion
9	34972-44022	Spacer
10	09160-05017	Washer
11	08313-11057	Nut
12	34189-44020	Pad
13	36380-11300	Case, Pilot Bulb
14	34981-44020	Cover, Under
15	09125-04011	Screw
16	34997-44020	Lock Washer
17	09160-04006	Washer
18	34952-11300	Bracket
19	01107-06308	Bolt
20	08322-21068	Washer
21	34955-11300	Cushion
22	34956-11300	Cushion
23	34978-11300	Spacer
24	09160-06004	Washer
25	08321-21068	Lock Washer
26	08310-11068	Nut
27	34949-30002	Guide, Throttle Cable
28	34954-44021	Clamp
29	02112-04068	Screw
30	08321-21048	Lock Washer
31	34289-11300	Pad
32	34995-31600	Cap
33	01107-06168	Bolt
34	08322-21068	Washer
35	34910-10211	Cable, Speedometer
36	34940-10302	Cable, Tachometer
37	34948-10300	Guide, Tachometer Cable
38	01107-06108	Bolt
39	08322-21068	Washer
40	08310-11068	Nut
41	34949-10300	Guide, Tachometer Cable




N° Réf.	N° Pièce	Désignation
1	35100-11300	Headlamp Assy
2	35111-44030	. . Rim
3	35127-33032	. . Ring
4	35121-11300	. . Unit
5	35171-36130	. . Socket
6	09471-12033	. . Bulb (12v, 35/35w)
7	02112-05108	. . Screw
8	08321-21058	. . Lock Washer
9	08310-22058	. . Nut
10	09125-05022	Screw
11	09162-05003	Lock Washer
12	09169-06021	Washer




N° Réf.	N° Pièce	Désignation
1	35100-44651	Headlamp Assy
2	35111-44030	. . Rim
3	35121-15617	. . Unit
4	35127-33032	. . Ring
5	35171-15616	. . Socket
6	09471-12033	. . Bulb (12v,35/35w)
7	36118-28660	. . Socket
8	09471-12001	. . Bulb (12v,3.4w)
9	02112-05108	. . Screw
10	08321-21058	. . Lock Washer
11	08310-11058	. . Nut
12	09125-05022	Screw
13	09162-05003	Lock Washer
14	09169-06021	Washer


N° Réf.	N° Pièce	Désignation
---------	----------	-------------

1	35100-11310-999	Headlamp Assy
2	35111-44630	. Rim
3	35121-18660	. Unit
4	35171-36650	. Socket
5	35172-28660	. Spring
6	36118-28660	. Socket
7	35128-29611	. Spring
8	09471-12020	Bulb (12v,35/35w)
9	09471-12063	Bulb (12v,4w)
10	09125-05022	Screw
11	09162-05003	Lock Washer
12	09169-06021	Washer






N° Réf.	N° Pièce	Désignation
1	35100-11330-999	Headlamp Assy
2	35111-44610	. Rim
3	35121-11320	. Unit
4	35136-34670	. Setting
5	35127-33630	. Ring
6	36118-30500	. Socket
7	35136-29610	. Screw
8	08321-21058	. Lock Washer
9	35172-33630	. Spring
10	35151-33630	. Screw
11	35154-33630	. Spring
12	35152-15611	. Nut
13	09471-12048	Bulb (12v,45/40w)
14	09471-12063	Bulb (12v,4w)
15	36853-30500	Lead Wire
16	09125-05022	Screw
17	09162-05003	Lock Washer
18	09169-06021	Washer




N° Réf.	N° Pièce	Désignation
1	35601-47012-999	Lamp, Front Turn Signal
2	35612-28620	. . Lens
3	35613-28620	. . Gasket
4	03211-04208	. . Screw
5	35627-43010	. . Gasket
6	09471-12056	Bulb (12v,21w)
7	35601-39160-999	Lamp, Rear Turn Signal
8	35612-28620	. . Lens
9	35613-28620	. . Gasket
10	03211-04208	. . Screw
11	35627-43010	. . Gasket
12	09471-12056	Bulb (12v,21w)
13	35690-32200	Cushion
14	35695-32200	Spacer
15	35629-44000	Washer
16	08321-21108	Lock Washer
17	08310-11108	Nut
18	08321-21108	Lock Washer
19	08322-11108	Washer
20	08310-22108	Nut
21	36660-33000	Lead Wire, Earth
22	36852-10300	Lead Wire, Earth
23	38610-45031	Relay Assy, Turn Signal




N° Réf.	N° Pièce	Désignation
1	35601-44032-999	Lamp, Front Turn Signal
2	35612-28620	. . Lens
3	35613-28620	. . Gasket
4	03211-04208	. . Screw
5	35627-43010	. . Gasket
6	09471-12056	Bulb (12v, 21w)
7	35603-36282	Lamp, Rear Turn Signal
8	35652-39280	. . Lens
9	35613-28620	. . Gasket
10	09471-12056	. . Bulb (12v,21w)
11	03211-04208	. . Screw
12	35627-43010	. . Gasket
13	35690-32200	Cushion
14	35695-32200	Spacer
15	35629-44000	Washer
16	08321-21108	Lock Washer
17	08310-11108	Nut
18	08321-21108	Lock Washer
19	08322-11108	Washer
20	08310-22108	Nut
21	36660-33000	Lead Wire, Earth
22	36852-10300	Lead Wire, Earth
23	38610-45031	Relay Assy, Turn Signal






N° Réf.	N° Pièce	Désignation
1	35601-34651-999	Lamp, Front Turn Signal
2	35612-28620	. . Lens
3	35613-28620	. . Gasket
4	02112-04258	. . Screw
5	35627-43010	. . Gasket
6	09471-12045	Bulb (12v,21w)
7	35603-44621-999	Lamp, Rear Turn Signal
8	35612-28620	. . Lens
9	35613-28620	. . Gasket
10	02112-04258	. . Screw
11	35627-43010	. . Gasket
12	09471-12045	Bulb (12v,21w)
13	35690-32200	Cushion
14	35695-36590	Spacer
15	09160-10006	Washer
16	08321-21108	Lock Washer
17	08310-11108	Nut
18	08321-21108	Lock Washer
19	08310-22108	Nut
20	36660-33000	Lead Wire, Earth
21	36852-10300	Lead Wire, Earth
22	38610-45090	Relay Assy, Turn Signal
23	36851-45010	Lead Wire, Relay Earth




N° Réf.	N° Pièce	Désignation
1	35710-11300	Lamp Assy, Tail
2	35712-30512	. . Lens
3	35713-30510	. . Gasket
4	09471-12035	. . Bulb (12v,23/8w)
5	09125-04002	. . Screw
6	35627-43010	. . Gasket
7	01107-06208	Bolt
8	09160-06027	Washer
9	09320-14010	Cushion, Front
10	09320-09012	Cushion, Rear
11	09180-06006	Spacer
12	01107-06168	Bolt
13	09160-06027	Washer
14	09320-09009	Cushion
15	09180-06011	Spacer
16	35726-10300	Bracket, Combination Lamp
17	35927-10301	Plate, Licence
18	01107-06128	Bolt
19	09180-06048	Spacer
20	08321-21068	Lock Washer
21	08310-11068	Nut


GT200 X



N° Réf.	N° Pièce	Désignation
1	35710-11321	Lamp Assy, Tail
2	35712-48622	. . Lens
3	35713-30510	. . Gasket
4	09471-12057	. . Bulb (12v,21/5w)
5	09125-04002	. . Screw
6	35627-43010	. . Gasket
7	01107-06208	Bolt
8	09160-06027	Washer
9	09320-14010	Cushion, Front
10	09320-09012	Cushion, Rear
11	09180-06006	Spacer
12	01107-06168	Bolt
13	09160-06027	Washer
14	09320-09009	Cushion
15	09180-06011	Spacer
16	35726-10300	Bracket, Combination Lamp
17	35927-10301	Plate, Licence
18	01107-06128	Bolt
19	09180-06048	Spacer
20	08321-21068	Lock Washer
21	08310-11068	Nut





N° Réf.	N° Pièce	Désignation
1	35710-11390-999	Lamp Assy, Tail
2	35712-30641	. . Lens
3	35713-30510	. . Gasket
4	35728-30640	. . Gromet
5	09125-04002	. . Screw
6	35627-43010	. . Gasket
7	09471-12046	Bulb (12v,21/5w)
8	01107-06208	Bolt
9	09160-06027	Washer
10	09320-14010	Cushion, Front
11	09320-09012	Cushion, Rear
12	09180-06006	Spacer
13	01107-06168	Bolt
14	09160-06027	Washer
15	09320-09009	Cushion
16	09180-06011	Spacer
17	35780-10390	Bracket, Combination Lamp
18	35927-10301	Plate, Licence
19	01107-06128	Bolt
20	09180-06048	Spacer
21	08321-21068	Lock Washer
22	08310-11068	Nut
23	35970-45611	Reflex Reflector, Rear
24	09180-06048	Washer
25	08310-11058	Nut




N° Réf.	N° Pièce	Désignation
1	36610-10302	Wiring Harness
2	09407-11301	Clamp (l:110)
2	09407-18301	Clamp (l:180)
2	09407-25301	Clamp (l:250)
3	09404-06401	Clamp
4	36618-30610	Boot
5	31800-10200	Relay, Starting Motor
6	01107-06168	Bolt
7	09160-06007	Washer
8	08310-22068	Nut
9	08321-21068	Lock Washer
10	33850-10300	Lead Wire, Starting Motor
11	31861-35100	Cap, Terminal
12	33885-10200	Gromet
13	32800-10200	Rectifier Assy, Regulator
14	02112-06208	Screw
15	08321-21068	Lock Washer
16	36740-15010	Fuse Case Assy
17	09481-15001	• Fuse (15a)
18	36791-46700	Holder, Fuse Case
19	37740-20010	Switch Assy, Stop Lamp
20	09443-06016	Spring
21	38500-10380	Horn
22	01107-06108	Bolt
23	37110-28655	Switch Assy, Ignition
24	37145-19710	Key, Blank
25	35950-45010	Reflex Reflector, Front
26	08321-21058	Lock Washer
27	08322-21058	Washer

N° Réf.	N° Pièce	Désignation
1	41100-10300-019	Frame (black)
2	41911-10200	Plate, Mounting Rh
3	41920-10200	Plate, Mounting Lh
4	01107-08758	Bolt
5	08310-22088	Nut
6	08322-11088	Washer
7	08321-21088	Lock Washer
8	09800-00108	Tool Set
9	41550-10200	Holder, Tool
10	09462-00072	Band
11	01107-06128	Bolt
12	09160-06019	Washer
13	08321-21068	Lock Washer
14	41611-10300	Grip, Frame Handle






N° Réf.	N° Pièce	Désignation
1	42100-10200	Stand, Center
2	09180-10001	Spacer
3	09101-10020	Bolt
4	08321-21108	Lock Washer
5	08310-11108	Nut
6	09385-10001	Clip
7	09443-18005	Spring
8	09321-10001	Cushion
9	42310-10300	Stand, Prop
10	09443-19003	Spring
11	09100-10007	Bolt
12	08310-22108	Nut
13	09320-07001	Cushion
14	43510-10200	Bar, Front Footrest
15	43551-39100	Rubber
16	01107-08168	Bolt
17	08321-21088	Lock Washer
18	43610-03001	Bar, Pillion Footrest
19	43612-03001	Rubber
20	09160-19006	Washer
21	09200-06010	Pin
22	04111-20208	Cotter Pin
23	43110-10200	Pedal, Brake
24	09448-31011	Spring
25	09160-15002	Washer
26	04111-30308	Cotter Pin
27	43300-10300	Lod Assy, Rear Brake
28	09440-09004	. Spring
29	09209-13003	. Pin
30	09150-06001	. Nut
31	08322-21068	. Washer
32	04111-20208	. Cotter Pin
33	08322-21058	. Washer




N° Réf.	N° Pièce	Désignation
1	42100-10200	Stand, Center
2	09180-10001	Spacer
3	09101-10020	Bolt
4	08321-21108	Lock Washer
5	08310-11108	Nut
6	09385-10001	Clip
7	09443-17007	Spring
8	09321-10001	Cushion
9	42310-10310	Stand, Prop
10	09443-11008	Spring, Inner
11	09443-19002	Spring, Outer
12	09111-10013	Bolt
13	08310-22108	Nut
14	09320-07001	Cushion
15	43510-10310	Bar, Front Footrest
16	43551-39100	Rubber
17	01107-08168	Bolt
18	08321-21088	Lock Washer
19	43610-03001	Bar, Pillion Footrest
20	43612-03001	Rubber
21	09160-19006	Washer
22	09200-06010	Pin
23	04111-20208	Cotter Pin
24	43110-10200	Pedal, Brake
25	09448-31011	Spring
26	09160-15002	Washer
27	04111-30308	Cotter Pin
28	43310-10300	Lod Assy, Rear Brake
29	09440-09004	. . Spring
30	09209-13003	. . Pin
31	09150-06001	. . Nut
32	08322-21068	. . Washer
33	04111-20208	. . Cotter Pin
34	08322-21058	. . Washer






N° Réf.	N° Pièce	Désignation
1	44100-10310-10V	Tank, Fuel (white)
2	68111-36400-538	. . Emblem
3	68110-10310-70K	. . Tape Set
4	44100-10310-05K	Tank, Fuel (blue)
5	68111-36400-538	. . Emblem
6	68110-10310-70K	. . Tape Set
7	44100-10310-07P	Tank, Fuel (red)
8	68111-36400-538	. . Emblem
9	68110-10310-69R	. . Tape Set
10	44200-30703	Cap Assy, Fuel Tank Filler
11	09329-10007	Cushion, Front
12	44541-10200	Cushion, Center
13	09320-12010	Cushion, Rear No.1
14	09320-12023	Cushion, Rear No.2
15	09180-08067	Spacer
16	09160-08002	Washer
17	01107-08708	Bolt
18	09180-08091	Spacer

N° Réf.	N° Pièce	Désignation
1	44300-11372	Cock Assy, Fuel
2	44357-32470	• Spring
3	44353-32470	• O Ring
4	44343-41370	• Screw
5	44348-28070	• O Ring
6	44346-28070	• Gasket
7	44347-28071	• Cup
8	09128-06006	Bolt
9	09168-06010	Gasket
10	09343-05031	Hose, Fuel (l:220@r190)
11	09401-08402	Clip







N° Réf.	N° Pièce	Désignation
1	44611-10200	Tank, Oil
2	44651-05003	Cap
3	44661-27000	Gasket
4	44600-31831	Oil Level Inspection Set
5	01107-06168	Bolt
6	09160-06007	Washer
7	08321-21068	Lock Washer
8	09344-05023	Hose, Breather
9	09401-08402	Clip
10	09407-11301	Clamp
11	44668-10200	Extension, Oil Tank Inlet
12	47111-10310-10V	Cover, Frame Rh (white)
13	68136-10310-70K	Tape, Rh
14	47111-10310-05K	Cover, Frame Rh (blue)
15	68136-10310-70K	Tape, Rh
16	47111-10310-07P	Cover, Frame Rh (red)
17	68136-10310-69R	Tape, Rh
18	47211-10310-10V	Cover, Frame Lh (white)
19	68146-10310-70K	Tape, Lh
20	47211-10310-05K	Cover, Frame Lh (blue)
21	68146-10310-70K	Tape, Lh
22	47211-10310-07P	Cover, Frame Lh (red)
23	68146-10310-69R	Tape, Lh
24	47117-45000	Cushion
25	68131-10300	Emblem
26	47130-10200	Knob
27	02142-06125	Stopper
28	09161-06015	Cushion

N° Réf. N° Pièce Désignation

1	45100-10301-86S	Seat (black)
2	09321-08006	Cushion
3	01107-08168	Bolt
4	09160-08010	Washer
5	08321-21088	Lock Washer
6	45510-10300-10V	Tail Cover, Seat (white)
7	45525-10300-10V	• Lid, Tail Cover (white)
8	45526-10300	• Spring
9	68160-10310-70K	Tape Set
10	45510-10300-05K	Tail Cover, Seat (blue)
11	45525-10300-05K	• Lid, Tail Cover (blue)
12	45526-10300	• Spring
13	68160-10310-70K	Tape Set
14	45510-10300-07P	Tail Cover, Seat (red)
15	45525-10300-07P	• Lid, Tail Cover (red)
16	45526-10300	• Spring
17	68160-10310-69R	Tape Set
18	08319-21068	Nut
19	09169-06010	Washer
20	46310-10300	Carrier, Sports




GT200EX



N° Réf.	N° Pièce	Désignation
20	51100-10300-291	Front Fork Assy
1	51130-10300	. . Outer Tube, Rh
2	51140-10300	. . Outer Tube, Lh
3	51153-29400	.. . Oil Seal
4	51158-36010	.. . Washer
5	51156-36010	.. . Ring, Oil Seal Stopper
6	51148-41310	.. . Gasket
7	51147-16510	. . Bolt
8	51173-29310	. . Dust Seal
9	51195-36220	. . Piece, Oil Lock
10	51146-10300	. . Cylinder
11	51110-10300	. . Inner Tube
12	51171-10300	. . Spring
13	51172-18630	. . Guide, Spring
14	51176-36211	. . Spacer
15	51181-25010	. . O Ring
16	51351-25011	. . Cap
17	51410-10300	. . Stem, Steering
18	51621-33001	.. . Outer Race
19	51311-29320-291	. . Stem Head, Steering
20	51356-22012	. . Washer
21	51351-20010	. . Bolt
22	56211-29320-291	. . Holder, Handle
23	01204-08357	. . Bolt
24	08321-21068	. . Lock Washer
25	51451-15113	. . Bolt
26	08321-21108	. . Lock Washer
27	51455-36010	. . Clip
28	51451-28012	. . Bolt
29	08321-21128	. . Lock Washer
30	51453-05110	. . Clip
31	02112-06108	. . Screw
32	08321-21068	. . Lock Washer
33	51530-11300-291	. . Bracket, Head Lamp Rh
34	51540-11300-291	. . Bracket, Head Lamp Lh
35	51553-10300	. . Gasket



GT200EA




N° Réf.	N° Pièce	Désignation
36	51100-10310-291	Front Fork Assy
1	51130-10310	. . Outer Tube Rh
2	51140-10310	. . Outer Tube Lh
3	51153-29400	.. .. Oil Seal
4	51158-36010	.. .. Washer
5	51156-36010	.. .. Ring, Stopper
6	51148-41310	.. .. Gasket
7	51147-16510	.. .. Bolt
8	51173-29310	.. .. Dust Seal
9	51195-36220	. . Piece, Oil Lock
10	51146-10300	. . Cylinder
11	51110-10300	. . Inner Tube
12	51171-10300	. . Spring
13	51172-18630	. . Guide, Spring
14	51176-36211	. . Spacer
15	51181-25010	. . O Ring
16	51351-25011	. . Cap
17	51410-10300	. . Stem, Steering
18	51621-33001	.. .. Outer Race
19	51311-29320-291	. . Stem Head, Steering
20	51356-22012	. . Washer
21	51351-20010	. . Bolt
22	56211-29320-291	. . Holder, Handle
23	01204-08357	. . Bolt
24	08321-21068	. . Lock Washer
25	51451-15113	. . Bolt
26	08321-21108	. . Lock Washer
27	51455-36010	. . Clip
28	51451-28012	. . Bolt
29	08321-21128	. . Lock Washer
30	511453-05110	. . Clip
31	02112-06108	. . Screw
32	08321-21068	. . Lock Washer
33	51530-11300-291	. . Bracket, Headlamp Rh
34	51540-11300-291	. . Bracket, Headlamp Lh
35	51553-10300	. . Gasket

GT200EX

N° Réf.	N° Pièce	Désignation
1	53110-10310	Fender, Front
2	01107-08168	Bolt
3	08321-21088	Lock Washer
4	58621-21203	Guide, Cable
5	51811-44000-291	Housing, Headlamp
6	01204-08257	Bolt
7	08322-11088	Washer
8	08321-21088	Lock Washer
9	09180-08030	Spacer
10	09329-12002	Cushion
11	51860-45000	Plate




GT200EX




N° Réf.	N° Pièce	Désignation
1	54111-11301	Wheel, Front
2	08123-63017	Bearing
3	09180-12041	Spacer (12.6*19*52)
4	54711-11301	Axle, Front
5	54740-11300	Spacer, Rh
6	08322-11128	Washer
7	08314-31128	Nut
8	04111-30308	Cotter Pin
10	54600-36200	Box Assy, Speedometer Gear
11	59211-36202	Disk, Front Brake
12	09100-08140	Bolt (8*28)
13	09169-08019	Washer
14	55100-36600	Tire (2.75-18)
15	55200-11601	Tube, Inner (2.75-18)
16	55411-47001	Balancer, Wheel No.1
17	55412-47001	Balancer, Wheel No.2



N° Réf.	N° Pièce	Désignation
1	54110-10202	Hub, Wheel
2	54210-10200	Panel
3	54410-32400	Shoe, Brake
4	55420-41100	Spring
5	54440-32402	Cam, Brake
6	09280-15001	O Ring
7	09160-15001	Washer
8	64451-30001	Lever, Brake Cam
9	01107-06408	Bolt
10	08322-21068	Washer
11	08310-11068	Nut
12	54611-36000	Gear, Speedometer
13	54621-10200	Pinion, Speedometer
14	54632-49200	Bush
15	09160-05001	Thrust Washer
16	54660-11031	Driver
17	09160-22001	Thrust Washer
18	08331-11229	Circlip
19	09285-26003	Oil Seal
20	09289-06001	Oil Seal
21	54711-11301	Axle, Front
22	09180-12041	Spacer
23	54740-10200	Spacer, Rh
24	08322-11128	Washer
25	08314-31128	Nut
26	04111-30308	Cotter Pin
28	08143-62017	Bearing, Lh
29	08123-62017	Bearing, Rh
30	55100-36600	Tire, Front
31	55200-11601	Tube, Inner
32	55261-11010	Protector, Inner Tube
33	55311-10300	Rim, Wheel
34	55300-10830	Spoke Set
35	55411-11000	Balancer, Wheel No.1
36	55412-11000	Balancer, Wheel No.2




GT200EX




N° Réf.	N° Pièce	Désignation
1	56111-10320	Handlebar (neutral Handle)
2	56111-10330	Handlebar (flat Handle)
3	56170-10200	Cover, Steering Head
4	56175-10200	Bracket
5	02112-04088	Screw
6	08321-21048	Lock Washer
9	56500-45640	Mirror Assy, Rear View
19	58200-10300	Cable, Clutch (neutral Handle)
19	58200-10310	Cable, Clutch (flat Handle)
20	58300-10300	Cable, Throttle (neutral Handle)
20	58300-10310	Cable, Throttle (flat Handle)
21	51910-25310	Lock Assy, Steering
22	02112-05128	Screw
23	08321-21058	Lock Washer
24	95700-04112	Lock Assy, Helmet
25	09407-12402	Band
26	51611-20002	Race, Steering Inner Upper
27	51611-33002	Race, Steering Inner Lower
28	51621-28000	Race, Steering Outer Upper
29	51631-28000	Nut, Steering Stem
30	51643-25001	Dust Seal
31	06111-06003	Steel Ball
32	06111-08003	Steel Ball

N° Réf.	N° Pièce	Désignation
1	57110-45000	Grip, Throttle
2	57420-49101	Lever, Brake
3	57431-18621	Bolt
4	08319-21068	Nut
5	37200-10300	Switch Assy, Handle Rh
6	37591-49210	• . Screw
25	09407-12402	Band




N° Réf.	N° Pièce	Désignation
1	57211-45020	Grip, Lh
2	57500-49101	Lever Assy, Clutch
3	57620-49101	. . Lever, Clutch
4	57431-11011	. . Bolt
5	08319-21068	. . Nut
6	57441-11010	. . Adjuster, Cable
7	57442-11010	. . Nut
8	01107-06208	. . Bolt
9	37400-49110	Switch Assy, Handle Lh
10	02112-05168	. . Screw
11	09407-12402	Band




GT200E1

N° Réf.	N° Pièce	Désignation
11	59100-47040	Calipers Assy
1	59100-47851	• . Piston & Pad Set
2	59107-34020	•• .. Seal, Piston
3	59108-34020	•• .. Boot, Piston
4	59111-34020	•• .. O Ring
5	59300-47840	•• .. Pad Set
6	59112-34020	•• .. Boot
7	59150-47020	• . Holder
8	02112-05108	• . Screw
9	08321-21058	• . Lock Washer
10	08322-21058	• . Washer
11	59305-45020	• . Axle, Calipers No.1
12	59306-45020	• . Axle, Calipers No.2
13	52474-60020	• . Cap
14	59121-34020	• . Bleeder
15	09103-10019	Bolt




GT200EX




N° Réf.	N° Pièce	Désignation
1	59600-49101	Cylinder Assy, Master
2	59600-49820	. Piston & Cup Set
3	59687-49000	. Reservoir
4	59688-49000	. Screw
5	59667-49000	. Diaphragm
6	59668-49000	. Plate
7	59669-49000	. Cap
8	59691-49000	. Screw
9	59686-49000	. O Ring
10	59671-49000	. Holder
11	59694-49001	. Bolt
12	59693-49001	. Bolt
13	59600-45210	Cylinder Assy, Master
14	59600-45841	. Piston & Cup Set
15	59687-45100	. Reservoir
16	59686-45100	. O Ring
17	59667-45100	. Diaphragm
18	59668-45101	. Plate
19	59669-45100	. Cap
20	59691-45100	. Screw
21	59692-45100	. Washer
22	59671-45100	. Holder
23	01107-06258	. Bolt
24	08322-21068	. Washer

N° Réf.	N° Pièce	Désignation
---------	----------	-------------


1	59711-49001	Boot, Master Cylinder
2	09360-10007	Bolt
3	09161-10005	Washer
4	59480-10321	Hose, Brake (neutral Handle)
4	59480-10331	Hose, Brake (flat Handle)
5	59243-11301	Guide, Hose No.1
6	51266-36200	Guide, Hose No.2
7	59244-36200	Grommet
8	01107-06108	Bolt
9	08321-21068	Lock Washer






N° Réf.	N° Pièce	Désignation
1	61100-10830-019	Rear Swinging Arm Set
2	61280-28000	• . Spacer, Center
3	09307-18002	• . Bushing
4	61211-10200	Shaft, Pivot
5	61251-28000	Spacer
6	61262-09200	Cover
7	09280-24001	O Ring
8	09160-12005	Thrust Washer
9	08322-11128	Washer
10	08319-21128	Nut
11	61273-36000	Buffer, Chain Defense
12	61310-36204	Chain Case
13	01107-06108	Bolt
14	01107-06128	Bolt
15	08321-21068	Lock Washer
16	62100-10300	Shock Absorber Assy, Rear
17	09160-10033	Washer (10.5*24*3.2)
18	09160-10001	Washer (10.5*24*2.3)
19	09160-12012	Washer, Rh (12.5*24*3.2)
20	08322-11128	Washer
21	08313-11108	Nut
22	64310-39000	Torque Link, Rear
23	09111-08012	Bolt
24	09111-08013	Bolt
25	08321-21088	Lock Washer
26	09140-08008	Nut
27	04111-20208	Cotter Pin







N° Réf.	N° Pièce	Désignation
1	63112-10201	Body, Rear Fender Front
2	63113-10300	Body, Rear Fender Rear
3	09329-05003	Cushion
4	01107-06128	Bolt
5	08322-21068	Washer
6	08321-21068	Lock Washer
7	09180-08052	Spacer (8.5*12*2.5)
8	01107-08308	Bolt
9	08322-11088	Washer
10	09320-12011	Cushion
11	09180-08021	Spacer (8.2*11.8*7.5)
12	08321-21088	Lock Washer
13	08310-12088	Nut
14	63120-10301	Reinforcement, Rear Fender
15	02142-06207	Screw
16	09180-06011	Spacer (6.1*9*9)
17	09320-08013	Cushion
18	09160-06012	Washer (6.5*22*1.6)
19	08321-21068	Lock Washer
20	08310-11068	Nut
21	63411-33000	Mud Guard, Rear Fender
28	63311-44600	Extension, Rear Fender
29	09125-06009	Screw
30	09180-06001	Spacer
31	09160-06028	Washer
32	08321-21068	Lock Washer
33	08310-11068	Nut



N° Réf.	N° Pièce	Désignation
1	64150-36400-12U	Wheel, Rear (18*1.60)
2	64210-39100	Panel, Rear Wheel
3	54410-07002	Shoe, Brake
4	09443-07001	Spring
5	54441-29302	Cam, Brake
6	09280-14003	O Ring
7	09160-14001	Washer (14.5*22*1.6)
8	64451-39100	Lever, Brake Cam
9	09100-06078	Bolt
10	08322-21068	Washer
11	08310-11068	Nut
12	64711-48000	Axle, Rear
13	09180-15042	Spacer, Lh (15*28*19)
14	09180-15002	Spacer, Rh (15.2*23*33)
15	08322-11148	Washer
16	09141-14001	Nut
18	04111-30308	Cotter Pin
19	08144-63027	Bearing, Rh
20	08143-62027	Bearing, Lh
21	09180-15011	Spacer (15.3*21.7*63)
22	64611-07000	Drum, Sprocket Mounting
23	64651-07001	Shock Absorber, Rear Wheel
24	64733-39100	Retainer, Drum
25	09285-28001	Oil Seal
26	08113-62040	Bearing
27	61410-36002	Adjuster, Chain
28	09104-08006	Bolt
29	08310-12088	Nut
30	64511-10300	Sprocket, Rear (nt:35)
31	09105-08001	Bolt
32	09169-08012	Lock Washer
33	08310-12088	Nut
34	65100-36600	Tire (3.00-18)
35	55200-11601	Tube, Inner
36	55411-47001	Balancer, Wheel No.1
37	55412-47001	Balancer, Wheel No.2



N° Réf.	N° Pièce	Désignation
1	64110-07603	Hub, Rear
2	64210-39100	Panel, Rear Hub
3	54410-07002	Shoe, Brake
4	09443-07001	Spring
5	54441-29302	Cam, Brake
6	09280-14003	O Ring
7	09160-14001	Washer (14.5*22*1.6)
8	64451-39100	Lever, Brake Cam
9	09100-06078	Bolt
10	08322-21068	Washer
11	08310-11068	Nut
12	64711-48000	Axle, Rear
13	09180-15042	Spacer, Lh (15*28*19)
14	09180-15002	Spacer, Rh (15.2*23*33)
15	08322-11148	Washer
16	09141-14001	Nut
18	04111-30308	Cotter Pin
19	08144-63027	Bearing, Rh
20	08143-62027	Bearing, Lh
21	09180-15011	Spacer (15.3*21.7*63)
22	64611-07000	Drum, Sprocket Mounting
23	64651-07001	Shock Absorber, Rear Hub
24	64733-39100	Retainer, Drum
25	09285-28001	Oil Seal
26	08113-62040	Bearing
27	61410-36002	Adjuster, Chain
28	09104-08006	Bolt
29	08310-12088	Nut
30	64511-10300	Sprocket, Rear (nt:35)
31	09105-08001	Bolt
32	09169-08012	Lock Washer
33	08310-12088	Nut
34	65100-36600	Tire
35	55200-11601	Tube, Inner
36	55261-11010	Protector, Inner Tube
37	65311-10300	Rim, Wheel (1.60*18)
38	65300-10830	Spoke Set
39	55411-11000	Balancer, Wheel No.1
40	55412-11000	Balancer, Wheel No.2



N° Réf.	N° Pièce	Désignation
1	99000-32030	Thread Lock, Super (13038)
2	09826-00001	Tool Set, Repairing
3	99000-25030	Grease, Super
4	99000-31030	Suzuki Bond, No.4
5	99000-32040	Cement, Thread Lock
6	99000-25140	Suzuki Moly Paste
7	99000-25100	Grease, Calipers Axle
8	99000-25110	Grease, Brake Pad
9	99000-21145	Cci Oil (11*24)
9	99000-21460	Cci Oil (11*24)
9	99000-21021	Cci Oil (4l*6)
9	99000-21150	Cci Oil (200l)
9	99000-21250	Cci Super Oil (11*24)
9	99000-21260	Cci Super Oil (4l*6)
10	99000-10105-019	Paint (black)
10	99000-10105-291	Paint (black Semi-glose)
10	99000-10205-05K	Paint (marble Canadian Blue)
10	99000-10205-07P	Paint (marble Pure Red)
10	99000-10205-10V	Paint (rocky White)
11	99000-10109-019	Paint (black)
11	99000-10109-291	Paint (black Semi-glose)
11	99000-10209-05K	Paint (marble Canadian Blue)
11	99000-10209-07P	Paint (marble Pure Red)
11	99000-10209-10V	Paint (rocky White)
12	11400-10830	Gasket Set